

Thermafiber® UltraBatt™ Mineral Wool Insulation

Manufacturers Fact Sheet

This fact sheet contains important details about Thermafiber's **UltraBatt™** mineral wool insulation. Please read carefully. The chart below covers all sizes of the UltraBatt™ unfaced insulation line. For more information, please visit our website at www.thermafiber.com.

Thermafiber® UltraBatt™ Mineral Wool Insulation

R-value	Thickness (inches)	Width (inches)	Length (inches)	Piece Sq. Ft.	Pieces/ Package	Package Sq. Ft.
10	2.5	16	48	5.33	8	42.7
10	2.5	24	48	8.00	8	64.0
15	3.5	15	47	4.90	5	24.5
15	3.5	16	48	5.33	5	26.7
15	3.5	23	47	7.51	5	37.5
15	3.5	24	48	8.00	5	40.0
23	5.5	15	47	4.90	4	19.6
23	5.5	23	47	7.51	4	30.0
24	6	16	48	5.33	4	21.3
24	6	24	48	8.00	4	32.0
30	7.1	15	47	4.90	3	14.7
30	7.1	23	47	7.51	3	22.5

Read This Before You Buy

What you should know about R-Values

The chart shows the R-values of this insulation. R means resistance to heat flow. The higher the R-value, the greater the insulating power. Compare insulation R-values before you buy.

There are other factors to consider. The amount of insulation you need depends mainly on the climate you live in. Also, your fuel savings from insulation will depend on the climate, the type and size of house, the amount of insulation already in your house, and your fuel-use patterns and family size. If you buy too much insulation, it will cost you more than what you'll save on fuel.

To get the marked R-value, it is essential that this insulation be installed properly.



UltraBatt™ insulation being installed in a residential wood stud wall.